

Model 1150D

marantz

console Stereo amplifier

PHONO
2/MG
TUNER
AUX
TAPE COPY
1-2
2-1

PLAY
OFF
REC 1
REC 2

SOURCE
1
2

LEFT TONE

RIGHT TONE

TURNOVER
200Hz
4KHz
30Hz
FILTERS
9KHz
9KHz
LEAD
HEADS

DOLBY B

tape monitor

BASS MID TREBLE

BASS MID TREBLE

RIGHT
LEFT
STEREO
STEREO
REVERSE
+ R

mode

VOLUME

volume

L-R
METER

IN
DUBBING
OUT

LEFT
RIGHT
RECORD LEVEL

LEFT RIGHT

balance

LEFT
RIGHT
PLAY CAL

AUDIO
MUTING

MAIN
SPEAKERS

REMOTE

400Hz
TONE

LEFT
RIGHT
MICROPHONE

TO
DEFATE

PHONES

POWER

Model 1150D

marantz

PHONO 1
2/MIC
TUNER
AUX
TAPE COPY 1-2
2-1

PLAY
OFF
REC I
REC II
DOLBY FM

SOURCE
1
2

DOLBY SYSTEM

tape monitor

LEFT TONE

RIGHT TONE

BASS

MID

TREBLE

BASS

MID

L R
METER

IN DUBBING OUT

LEFT RIGHT
RECORD LEVEL

LEFT

RIGHT

balance

400Hz
TONE

LEFT MICROPHONE
RIGHT

arantz

console *Stereo* amplifier

RIGHT TONE + +

TURNOVER 250Hz 4KHz FILTERS 30Hz 5KHz 9KHz LOUDNESS

BASS MID TREBLE

mode

volume

RIGHT

balance

LEFT RIGHT

PLAY CAL

AUDIO MUTING

TONE DEFEAT

PHONES

MAIN SPEAKERS

REMOTE

POWER



