

## WANT TO KNOW MORE ?

Go online for further support services:



[www.goodmans.co.uk/support](http://www.goodmans.co.uk/support)


CD Micro System with  
Bluetooth and USB playback

Model: GMCO1


QSG-JUNE14-GMCO1

# Goodmans

## Bluetooth CD Micro System



## GETTING STARTED:



## PLAYING A CD


- (a)** Plug one end of the power cord into the back of the system and the other end into the mains socket.
- (b)** Open the CD compartment lid. Insert the CD with the label facing upwards and then close. It will begin playing automatically.

## USING FM RADIO

- (a)** On the top of the unit, press the FUNC button to switch to FM mode
- (b)** Press the M+/PMODE button to select the desired radio station.

## DID YOU KNOW ?

There are a number of ways you can play audio from an external source using the CD Micro System.



## USB PORT

- (a)** Using the display panel to guide you, press the FUNC button to switch to USB mode.
- (b)** Connect a USB drive to the USB socket. It will begin playing automatically.

## BLUETOOTH

- (a)** Using the display panel to guide you, press the FUNC button to switch to BLUETOOTH mode.
- (b)** On your device, switch bluetooth on and select GMC01 from the list. The display panel on the CD Micro System will tell you when both devices are connected.

## CONNECTING DEVICES USING A LINE IN CABLE

- (a)** Using the display panel to guide you, press the FUNC button to switch to AUX mode.
- (b)** Connect one end of the line in cable to your device and the other to the AUX socket.
- (c)** Control the music from your device.