

Bang & Olufsen

M A S T E R P A N E L A V 9 0 0 0

This manual was scanned by
and available FREE at www.lconic-AV.co.uk

- 4 Beosystem AV 9000
- 5 Placement
- 6 Connections
- 7 Assembling
- 8 Ready for use...
- 9 Maintenance
- 10 International Guarantee

This setting-up guide explains how to assemble the Master Panel AV 9000 and make it ready for use. We recommend that you follow the instructions carefully.

For instructions on setting up the other components in your Beosystem AV 9000, please refer to the setting-up guides enclosed with these products.


See the Master Panel AV 9000 user's guide for detailed operating instructions.

**This manual was scanned by
and available FREE at www.lconic-AV.co.uk**

Do not connect the Master Panel AV 9000 to the mains until you have finished the setting-up procedure and connected all the cables.

The following parts are required to set up the Master Panel AV 9000 and to connect it to your Beocenter AV 9000:



- one set of glass doors (left and right)
- one cable cover, to conceal and hold the cables on the rear of the Master Panel AV 9000
- one Master Link cable for connection to the Beocenter AV 9000
- one lead for connection to the mains




Before you start...

When setting up the Master Panel AV 9000 we suggest you use the following sequence:

- 1 Place the Master Panel AV 9000 where you want to use it.
- 2 Connect all cables to their sockets on the rear panel of the Master Panel AV 9000 (only remember not to connect it to the mains yet!).
- 3 Arrange the cables in the grooves of the cable cover and attach the cover to the rear of the Master Panel AV 9000.
- 4 Loosen the transport protection screw for the CD drive mechanism.
- 5 Attach the glass doors.
- 6 Set up the other parts of your Beosystem AV 9000.
- 7 Connect all the products to the mains.



Complete the setting-up procedure as described in the *Setting-up guide* for the Beocenter AV 9000 (calibration of speakers etc.)



A Beosystem AV 9000 setup can be composed in different ways to your personal taste and home environment.


This setup is based on the Beocenter AV 9000 and the Master Panel AV 9000. It has a pair of Beolab 8000 as front speakers and a pair of Beolab 6000 as rear speakers.

Daily operations are carried out from the Master Panel AV 9000 by direct operation and through on-screen menus.

The Beolink 5000 remote control gives access to secondary functions not otherwise available and we therefore recommend it as an indispensable part of the system.

The setup is shown with both front and rear speakers connected. However, if you wish so, you can set up the system with only a set of front speakers connected.

**This manual was scanned by
and available FREE at www.Iconic-AV.co.uk**



Master Panel AV 9000 placed on its stand with one extra shelf.

The Master Panel AV 9000 is designed for a variety of placements.


Its compactness facilitates a placement next to your favourite listening/viewing position, which is also optimal for easy operation of the complete Beosystem AV 9000.

Make sure, when deciding where to place the Master Panel AV 9000, that you can see - and read - the on-screen menus on the Beocenter AV 9000.

The Stand is an optional extra for the Master Panel AV 9000. This stand has a small integrated shelf with room to accommodate a few compact discs and cassette tapes. If you wish, you can supplement the shelf by one or more extra shelves.

The stand is supplied with two different sets of feet:

- *spikes* for use on carpeted floors
- *rubber* feet for use on non-carpeted floors




The socket panel on the rear of the Master Panel AV 9000 is equipped with a socket for mains supply, two sockets for aerial connection (FM & AM) and a Master Link socket for connection to the Beocenter AV 9000.

Connect the FM aerial to the socket marked FM and the AM aerial, if any, to the socket marked AM.

Connect the Master Link cable to the Master Link socket on the Master Panel and the other end of the cable to the Master Link socket on the Beocenter AV 9000.

Connect the mains lead to its socket, but do not connect it to the mains yet.

This manual was scanned by
and available FREE at www.Iconic-AV.co.uk




Arrange the connector cables in the cable cover as shown

and

fasten the cable cover to the rear panel grill of the Master Panel AV 9000:

- Insert the bottom row of pegs into the grill.
- Push the top row of pegs into the grill.
- Pull the cable cover upwards until the pegs mesh properly with the grill.



Transport protection


The transport protection screw for the CD drive mechanism is located under the CD clamp.

Lift the clamp manually to gain access to the screw.

Loosen the screw by turning it counter-clockwise until it feels springy.

Then lower the CD clamp again.

CD transport protection screw




Glass doors

The labels on the back of the glass doors indicate which end must point up, and which side must point towards the centre.

Fasten the two glass doors, one at a time, to the front of the Master Panel AV 9000 by pressing their fastening points into the corresponding fastening sockets on the Master Panel.

Press gently on each of the four fastening points until you hear a click. The click indicates that the glass doors are properly seated.



**This manual was scanned by
and available FREE at www.lconic-AV.co.uk**

Note: Treat the glass doors with care! If they crack or chip or if they are damaged in any other way, they should be replaced immediately as they could otherwise cause bodily harm. You can order replacement doors through your Bang & Olufsen dealer.

When you have finished setting up the other parts of your Beosystem and have connected the Master Panel AV 9000 to the Beocenter AV 9000 as described, switch on at the mains.

A red light appears in the display of the Master Panel AV 9000 indicating that the system is in stand-by mode, ready to be used.

The Master Panel AV 9000 is a complete AV operation unit with integrated audio sources. It cannot be used on its own, but is designed to be used connected to the Beocenter AV 9000, thus creating a complete Beosystem AV 9000.

Please refer to the *User's guide* on making the various presettings etc.

See also the separate *Setting-up guide* for the Beocenter AV 9000 on how to proceed with the remaining steps in setting up your Beosystem AV 9000.

**This manual was scanned by
and available FREE at www.lconic-AV.co.uk**

Note!

If you move the Master Panel AV 9000 to another place, you must switch it off at the mains before unplugging the mains lead.

