

# FENDER® JAZZMASTER™ ULTRALIGHT LOUDSPEAKER ENCLOSURE

Your new Jazzmaster™ Ultralight loudspeaker features a Jensen® 12" (30.5 cm) speaker with a neodymium magnet, handling up to 250 watts of power. Designed to complement the Fender® Jazzmaster Ultralight amplifier, the Ultralight speaker cabinet is constructed from quality Italian poplar plywood. Please read these instructions and your amplifier manual before making connections.

## Ultralight Connections



To connect the Jazzmaster™ Ultralight speaker to an Ultralight amplifier, use the Speakon® cable included with the amplifier. Rotate the Speakon® connector to align it with the input slots, then fully insert the connector.



Rotate the connector clockwise until it locks into place.



## Disconnecting

Slide the locking tab back on the connector while rotating the connector counter-clockwise. Pull the connector out from the input socket.

## Non-Speakon® Connections

If your amplifier does not have a Speakon® speaker output, you will need the appropriate speaker cable or adapter to connect the Jazzmaster™ Ultralight loudspeaker. Speaker cable should be 2-conductor, 16-gauge minimum with the Speakon® connector wired:

1+ pin = Positive

1- pin = Negative



## SPECIFICATIONS

PART NUMBER	2277700000
SPEAKER	One 12" (30.5 cm) steel frame driver 2" (5.1 cm) voice coil Neodymium magnet
CABINET	5/8" (1.6 cm) Italian Poplar plywood
SENSITIVITY	98.5 dB, 1 Watt - 1 Meter
POWER HANDLING	250 Watts
IMPEDANCE	2 ohms
CONNECTIONS	4-Pole Speakon® Connector using Pins 1+ and 1-
ENCLOSURE VOLUME	V <sub>B</sub> = 0.8 ft <sup>3</sup> (38.7 L)
DIMENSIONS	
Height:	15 1/4 in (38.7 cm)
Width:	15 1/4 in (38.7 cm)
Depth:	10 1/4 in (26.0 cm)
WEIGHT	16 lb (7.3 kg)

*Product specifications are subject to change without notice.*

A PRODUCT OF:  
FENDER MUSICAL INSTRUMENTS CORPORATION  
CORONA, CALIFORNIA USA

Fender® and Jazzmaster™ are trademarks of FMIC.  
Other trademarks are property of their respective owners.  
© 2005 FMIC. All rights reserved.