


NOTES: UNLESS OTHERWISE SPECIFIED,
 1. ALL RESISTORS IN OHMS, $\pm 5\%$, 1/2W.
 2. ALL CAPACITORS IN MFD AT 100V.
 3. \ominus INDICATES SCREWDRIIVER ADJUSTMENT.
 4. ADJUST TR-1 (BIAS POT) AT 120V LINE,
 4 OHM LOAD, 5MV ACROSS R27 AND R29.

COMPONENT BASING

BOTTOM VIEWS

TOP VIEWS



SUPER THOR BASS AMPLIFIER SCHEMATIC DIAGRAM (Later Version)