

TD-1200

Owner's Manual Supplement



Addition to "Broadcast Station Programming" on page 8.

For programming a station which transmits Dolby-encoded broadcasts, proceed as follows.

(1) Extend the car antenna fully and adjust the tuner to receive the desired broadcast station.

(2) Press the memory switch.

(3) Out of the five station memory buttons, press the one you want to program the station into.

The indicator above the station memory button, which was glowing dimly, is now lit brightly to indicate that a station has been programmed.

(4) Press the Dolby NR switch. The "B" indicator lights up.

The broadcast station is now memorized for reception with the Dolby NR system in the "on" condition.

- For programming the Dolby NR "on" condition together with the broadcast station frequency, the Dolby NR switch must be operated after the station memory button was pushed and the button indicator is lit brightly.

If the Dolby NR switch is operated before the station memory button, the "on" condition cannot be memorized.

The same applies when the Dolby NR system is to be set to "off" for a station button memorized with the "on" condition (push the Dolby NR switch after the station memory button).