

## circuit diagram

M12616 iss 3

For use with tuners from Serial Number 11,000 onwards PCB No M12615 iss 5

c63 - 0.47uf - 50v - bipolar

c4 - 1000uf - 25v

c5 - 1000uf - 25v

c6 - 220uf - 25v

c11 - 100uf - 6.3v

c12 - 100uf - 6.3v

c30 - 2.2uf - 50v

c34 - 100uf - 6.3v

c37 - 2.2uf - 50v

c56 - 22uf - 40v

c57 - 470uf - 10v

electrolytic capacitors  
on the device at its design

Futaba 7-MT-172Y

the fuse is integrated  
into the mains socket

RIFA - 0.047uf + 100R - 275v X2

