



- NOTES: 1) S2-1, S2-2 PHONO SELECTOR SW (MAGCER)  
 2) SI-1, SI-2 SOURCE SELECTOR SW (1. PHONO 2. TAPE 3. TUNER)  
 3) ALL RESISTANCE VALUES ARE INDICATED IN "OHM" (K=10<sup>3</sup> OHM, M=10<sup>6</sup> OHM)  
 4) ALL CAPACITANCE VALUES ARE INDICATED IN "μF" (PF = 10<sup>6</sup> μF)

CAUTION: SINCE THE COMPONENTS MARKED BY  $\Delta$  ARE CRITICAL FOR SAFTY USE ONES DESCRIBED ON PARTS LIST

AC220V  
50Hz