
EH-195
MICROPHONE INPUT
INSTRUMENT INPUTS
TREBLE CONTROL
BASS CONTROL
ECHO SPEAKER JACK
A1011
110V AC
110 VOLTS A.C. OR D.C.
22V AC
4.8V AC
BREAK P.C. CIRCUIT AT X TO WIRE IN TUBES FOR VIBRATO
ONLY DIRECT GROUND TO CHASSIS