

"TRADER" SERVICE SHEET

1138

# FERGUSON 325 SERIES

Covering Table Models 325A, 325U and Radiograms 326RG, 326URG

**E**MPLYING a negative feed-back tone control circuit, the Ferguson 325A is a 4-valve (plus rectifier) 3-band A.C. table superhet, designed to operate from A.C. mains of 200-250 V, 50 c/s. The wavebands covered are 15.7-55.4 m, 184-575 m and 733-2,050 m.

Model 325U is the A.C./D.C. version of model 325A, and models 326RG and 326URG are the A.C. and A.C./D.C. 3-speed auto-radiogram versions respectively.

Release date, all models, August 1953. Original prices: 325A, 325U, £19 17s 6d.; 326RG; £54 17s.; 326URG, £61 4s 3d. Purchase tax extra.

### CIRCUIT DESCRIPTION

Aerial input via coupling coils **L1** (S.W.) and **L2** (M.W. and L.W.) to single-tuned circuits **L3, C34** (S.W.), **L4, C34** (M.W.) and **L5, C34** (L.W.), which precede triode hexode valve (**V1, Mullard ECH42** (A.C. model) or **UCH42** (A.C./D.C. model)) operating as frequency changer with internal coupling. **R1, C2** shunts the aerial input circuit on M.W., and **C2** shunts it on L.W., to move its resonance outside the tuning range. The

**E** socket is isolated from chassis in the A.C./D.C. model by **C40**.

Second valve (**V2, Mullard EBF80** (A.C. model) or **UBF80** (A.C./D.C. model)) is a double diode variable-mu R.F. pentode, its pentode section operating as intermediate frequency amplifier with tuned transformer couplings **C5, L10, L11, C6** and **C17, L12, L13, C18**.

Intermediate frequency 470 kc/s

One diode section of **V2** operates as signal detector, the audio frequency component in its rectified output being developed across volume control **R15**, which acts as diode load, and passed via **C21** to control grid of pentode A.F. amplifier (**V3, Mullard EF41** (A.C. model) or **UF41** (A.C./D.C. model)).

Provision is made for the connection of a gramophone pick-up across the volume control via **S17**, which closes in the gram position of the waveband control. **S15** and **S16** open in this position to prevent radio break-through. In the A.C./D.C. model the pick-up is shunted by **R38** and isolated from chassis by **C41** and **C42**.


Resistance-capacitance coupling by **R19, C25** and **R20** between **V3** and pentode output valve (**V4, Mullard EL41** (A.C. model) or **UL41** (A.C./D.C. model)). Variable tone control by **R25** in the negative feed-back network **R23, R24,**

**R25, C26** between the speech coil circuit and **V3** cathode. In the A.C./D.C. model, a third winding **c** is provided on the output transformer **T3** to supply the feed-back network **R28, R29, R30, C44**, and a phase-correcting capacitor **C43** is added between the top end of the network and **V4** anode.


In the A.C. model, H.T. current is supplied by I.H.C. full-wave rectifying valve (**V5, Mullard EZ40**). Smoothing by **R26, R27** and electrolytic capacitors **C27, C28** and **C29**. The heaters of all the valves, including **V5**, are fed from winding **a** on transformer **T2**.

In the A.C./D.C. model, H.T. current is supplied by I.H.C. half-wave rectifying valve (**V5, Mullard UY41**). Smoothing by **R32, R33** and electrolytic capacitors **C45, C46** and **C47**. The valve heaters, together with the scale lamps and ballast resistor **R37**, are connected in series across the mains input. **R34** protects the scale lamps, and **R36** protects **V5** from current surges. In the event of scale lamp failure, **R35** (**Brimistor CZ2**) carries the heater current and prevents **R34** from being overloaded.

Bias for **V1** and **V2** is obtained from the voltage dropped across **R22** (A.C. model) or **R31** (A.C./D.C. model) in the H.T. negative lead to chassis, the negative side of the reservoir capacitor being taken to this negative line.



Circuit diagram of the Ferguson 325A A.C. table superhet. The radiogram version, model 326RG, employs an identical circuit. The output and mains input stages of the A.C./D.C. table version, model 325U, are shown on the right of the main circuit diagram.



Appearance of models 325A and 325U.

**RADIOGRAM MODELS**

**Model 326RG.**—This is an A.C. console radiogram, employing a chassis identical to that used in model 325A, together with a 3-speed Garrard RC75 A.C. record changer.

**Model 326URG.**—This is an A.C./D.C. console radiogram and employs a Garrard RC75 3-speed A.C./D.C. record changer. It uses a 325U chassis but differs from the 325U circuit shown below in the following respects.

**C40** is increased to 0.05  $\mu$ F, **C42** is reduced to 0.05  $\mu$ F. A 150 k $\Omega$  resistor is inserted between **C41** and **S17**. **R38** is removed, and a 1 M $\Omega$  resistor is shunted from the lower end of **S17** to chassis. An 0.005  $\mu$ F capacitor is connected across winding **a** on **T3**. The scale lamps, together with **R34** and **R35**, are removed from the chassis side of the mains input circuit and connected between the junction

tion of **C48** and **L16**, and the junction of **R36** and **R37**. A 1 amp fuse is connected between **S20** and **L16**.

**COMPONENTS AND VALUES**

Resistors	A.C. Models	A.C./D.C. Models	Locations
R1	3-3k $\Omega$	3-3k $\Omega$	F3
R2	1-5 $\Omega$	—	F4
R3	1M $\Omega$	1M $\Omega$	G3
R4	22k $\Omega$	18k $\Omega$	G4
R5	33k $\Omega$	27k $\Omega$	G3
R6	47k $\Omega$	47k $\Omega$	G3
R7	3-3k $\Omega$	3-3k $\Omega$	G3
R8	27k $\Omega$	22k $\Omega$	G4
R9	250 $\Omega$	220 $\Omega$	F3
R10	470k $\Omega$	470k $\Omega$	F4
R11	470k $\Omega$	470k $\Omega$	E4
R12	100k $\Omega$	100k $\Omega$	G4
R13	470k $\Omega$	470k $\Omega$	E4
R14	100k $\Omega$	100k $\Omega$	B2
R15	500k $\Omega$	500k $\Omega$	E3
R16	3-3M $\Omega$	3-3M $\Omega$	F4
R17	1M $\Omega$	4-7M $\Omega$	E4
R18	100k $\Omega$	100k $\Omega$	E4
R19	220k $\Omega$	1M $\Omega$	E4
R20	1M $\Omega$	1M $\Omega$	E4
R21	180 $\Omega$	270 $\Omega$	E4
R22	47 $\Omega$	—	E3
R23	3-3k $\Omega$	—	B1
R24	27k $\Omega$	—	E4
R25	2-5k $\Omega$	—	D3
R26	680 $\Omega$	—	D4
R27	820 $\Omega$	—	D4
R28	—	10k $\Omega$	—
R29	—	47k $\Omega$	—
R30	—	2-5k $\Omega$	—
R31	—	33 $\Omega$	—
R32	—	680 $\Omega$	—
R33	—	1-5k $\Omega$	—
R34	—	330 $\Omega$	—
R35	—	†	—
R36	—	130 $\Omega$	—
R37	—	1-1k $\Omega$ *	—
R38	—	47k $\Omega$	—

\* Tapped at 700 $\Omega$ +200 $\Omega$ +200 $\Omega$  from L16.  
† Brimistor CZ2.

CAPACITORS		Values	Locations
C1	Aerial coupling ...	0-001 $\mu$ F	F3
C2	Aerial shunt ...	500pF	F3
C3	V1 C.G. ...	200pF	G3
C4	V1 S.G. decoupling ...	0-1 $\mu$ F	G3
C5	1st I.F. trans. ...	100pF	A2
C6	tuning ...	100pF	A2
C7	V1 osc. C.G. ...	50pF	G3
C8	S.W. osc. tracker...	3,550pF	G3
C9	M.W. osc. tracker	560pF	G3
C10	L.W. osc. trackers	500pF	F3
C11		200pF	G4
C12	Osc. anode coup....	200pF	G3
C13	A.G.C. decoupling	0-1 $\mu$ F	G4
C14	A.G.C. coupling ...	50pF	F4
C15	V2 S.G. decoupling	0-1 $\mu$ F	G4
C16	G.B. decoupling ...	0-1 $\mu$ F	E4
C17	2nd I.F. trans. ...	100pF	B2
C18	tuning ...	180pF	B2
C19	I.F. by-passes ...	100pF	B2
C20		100pF	B2
C21	A.F. coupling ...	0-005 $\mu$ F	F4
C22	V3 S.G. decoupling	0-05 $\mu$ F	E4
C23*	V4 cath. by-pass ...	50 $\mu$ F	E3
C24	V3 anode decoupl.	0-1 $\mu$ F	E4
C25	A.F. coupling ...	0-001 $\mu$ F†	E4
C26	Part tone control...	0-02 $\mu$ F†	E4
C27*	H.T. smoothing ...	32 $\mu$ F	D3
C28*		24 $\mu$ F	C1
C29*		24 $\mu$ F	C1
C30	Mains R.F. by-pass	0-01 $\mu$ F	E3
C31†	S.W. aerial trim...	15pF	F3
C32†	M.W. aerial trim...	40pF	F3
C33†	L.W. aerial trim...	65pF	F3
C34†	Aerial tuning ...	525pF§	B1
C35†	Oscillator tuning...	525pF§	B2
C36†	S.W. osc. trim. ...	15pF	F4
C37†	M.W. osc. trim. ...	40pF	F4
C38†	L.W. osc. trim. ...	65pF	F4
C39†	L.W. osc. tracker...	80pF	G4
C40	"E" socket isolator	0-005 $\mu$ F	—
C41	P.U. isolators ...	0-005 $\mu$ F	—
C42		0-1 $\mu$ F	—
C43		100pF	—
C44		Part tone control...	0-01 $\mu$ F
C45*	H.T. smoothing ...	32 $\mu$ F	—
C46*		24 $\mu$ F	—
C47*		24 $\mu$ F	—
C48	Mains R.F. by-pass	0-01 $\mu$ F	—

\* Electrolytic. † Variable. ‡ Pre-set.  
§ 0-003 $\mu$ F in A.C./D.C. models § "Swing" value, min. to max.






Table 326RG, 1 mains diagram.



OTHER COMPONENTS		Approx. Values (ohms)	Locations	
L1	Aerial coupling coils ...	2-3	A1	
L2		28-0	A1	
L3		—	A1	
L4	Aerial tuning coils	2-6	A1	
L5		30-0	A1	
L6	Oscillator tuning coils ...	—	G3	
L7		2-5	G3	
L8	15-0	G3		
L9	Osc. reaction coil...	1-0	G3	
L10	1st I.F. trans. { Pri. ...	8-0	A2	
L11		8-0	G3	
L12	2nd I.F. trans. { Pri. ...	8-0	B2	
L13		6-0	B2	
L14	Speech coil ...	2-5	—	
L15	Mains filter chokes { a ...	3-4	—	
L16		3-4	—	
T1	O.P. trans. (A.C. model) { a ...	460-0	B1	
T2	Mains trans. { a ...	380-0	C1	
		380-0		
		44-0		
T3	O.P. trans. (A.C./D.C. model) { a ...	290-0	—	
		13-0		
		—		
S1-S17	Waveband switches	—	F3	
S18	Speaker switch ...	—	E4	
S19, S20	Mains sw., g'd R25	—	D3	

The circuit on the immediate left shows the principal differences in the A.C./D.C. table model 325U as compared with the A.C. model 325A.



Waveband switch units.


**GENERAL NOTES**

**Switches.**—S1-S17 are the waveband and radio/gram change over switches, ganged in two rotary units beneath the chassis. These units are indicated in our underside view of the chassis, and shown in detail in the diagrams above where they are drawn as seen from the rear of an inverted chassis. The associated switch table below gives the switch operations for the four control positions starting from the fully anti-clockwise setting of the knob. A dash indicates open and C closed.

Switches	Gram	L.W.	M.W.	S.W.
S1	—	—	—	C
S2	—	—	—	—
S3	—	—	—	—
S4	—	—	—	—
S5	—	—	—	—
S6	—	—	—	—
S7	—	—	—	—
S8	—	—	—	—
S9	—	—	—	—
S10	—	—	—	—
S11	—	—	—	—
S12	—	—	—	—
S13	—	—	—	—
S14	—	—	—	—
S15	—	—	—	—
S16	—	—	—	—
S17	C	—	—	—

**Scale lamps.**—In the A.C. models these are 6.5 V, 0.3 A lamps with M.E.S. bases and small clear spherical bulbs. In the A.C./D.C. models 8 V, 0.15 A lamps are used.

**Tuning Drive Replacement, Table Models.**—About 66 inches of high-quality flax fishing line, plaited and waxed, is required for a new drive cord. The drive should be run as shown in the sketch (the upper one (on right) at foot of cols. 2 and 3) starting off with the gang at maximum capacitance and securing one end of



Positions of the calibration points on the scale backing plate in the gram models.

the drive cord to the drive drum bush. When the two cursors are finally replaced on the cord, they should be positioned so that with the gang at maximum capacitance they coincide with the high wavelength ends of their respective tuning scales.

**Tuning Drive Replacement, Gram Models.**—About 72 inches of high-quality flax fishing line, plaited and waxed, is required for a new drive cord. First, the scale backing plate and the waveband indicator should be removed. The cord should then be run as shown in the sketch in col. 4, starting off with the gang at maximum capacitance and anchoring one end of the cord to the tag on the front of the drive drum.

**Waveband Indicator Drive.**—For the table models about 42 inches of cord is required and should be run as shown in the lower sketch below, first threading the eyelet on to the cord and then tying the free ends of the cord to the drive drum.



The waveband indicator used in the gram models consists of a sliding metal bar which is pulled against the tension of

a spring by an arm on the switch spindle. The bar and arm are connected by a cord which passes round a pulley and is connected to a tag on the back of the bar. This tag also serves as an anchor point for the tension spring, the other end of the spring being hooked through a hole in the top flange of the tuning scale frame. When fitting a new cord, the length between the knotted ends of the cord should be 6 inches.

**MODIFICATIONS**


**A.C. Table Models 325A.**—Some early receivers were fitted with mains transformer whose H.T. secondary voltage was 290-0-290 V. In these receivers R26 was 470 Ω, R27 was 1.8 kΩ, and the voltage across C27 was 310 V. The H.T. feed to V4 anode circuit was taken from the junction of R26 and R27.

**Model 326RG.**—Early versions of this receiver incorporated all the items listed above. In addition C31, C33, C36 and C38 had a maximum capacitance of 40 pF each. A 20 pF capacitor was connected in series with C36, and a 30 pF capacitor was connected in parallel with C38.



Above: Sketch of the tuning drive system as used in table models 325A and 325U.

Left: Sketch of the waveband indicator drive system as used in the table models.



Turning drive system for gram models, viewed from the front.

**VALVE ANALYSIS**

Valve voltages and currents given in the tables below are those derived from the manufacturers' information. They were measured on receivers operating from A.C. mains of 230 V, with voltage adjustments set to the 220-230 V tapings. The receivers were tuned to the high wavelength end of the M.W. band, but there was no signal input.

Voltages were measured on the 10 V and 400 V ranges of a Model 7 Avometer, chassis being the negative connection in every case. The negative voltage measured across R22 was 2.6 V; across R31 it was 2.1 V.

**A.C. Model**


Valve	Anode		Screen		Cath.
	V	mA	V	mA	
V1 ECH42	250 Oscillator 115	2.7 4.7	100	3.7	—
V2 EBF80	268	4.3	80	1.7	—
V3 EF41	35	0.5	20	0.1	1.0
V4 EL41	265	35.0	250	5.0	6.8
V5 EZ40	270*	—	—	—	285.0†

\* A.C. reading. † Cathode current, 61 mA.

**A.C./D.C. Model**

Valve	Anode		Screen		Cath.
	V	mA	V	mA	
V1 UCH42	184 Oscillator 75	2.3 4.4	75	4.7	—
V2 UBF80	184	3.7	82	1.5	—
V3 UF41	†	†	†	†	0.25
V4 UL41	218	40.0	212	7.0	12.5
V5 UY41	—	—	—	—	322.0§

† Very low. § Cathode current, 64 mA.



Plan view of the A.C. chassis. The external speaker switch plug is indicated.

**CIRCUIT ALIGNMENT**

In the table models, all the trimmer and core adjustments can be made accessible by removing the cabinet base and back covers. In the gram models, however, it is necessary to remove the chassis.

**I.F. Stages.**—Switch receiver to M.W. and turn gang to maximum capacitance. Connect output of signal generator, via an 0.1 μF capacitor in each lead, to control grid (pin 6) of V1 and chassis. Feed in a 470 kc/s (638.3 m) signal and adjust the cores of L13 (location reference B2), L12 (F4), L11 (A2) and L10 (G4) for maximum output.

**R.F. and Oscillator Stages.**—In the gram models the tuning scale is fixed to the cabinet, and as the chassis is removed to give access to the trimmers, the calibration points given in the following alignment instructions must be marked off in pencil on to the scale backing plate to form a substitute tuning scale. The positions of these calibration points relative to the right-hand end of the backing plate (viewed from front of chassis) are shown in the substitute tuning scale sketch at the head of columns 2 and 3. Transfer generator leads to A and E sockets.

**L.W.**—Switch receiver to L.W., tune to 857 m, feed in an 857 m (350 kc/s) signal and adjust C38 (F4) and C33 (F3) for maximum output. Tune receiver to 1,875 m, feed in a 1,875 m (160 kc/s) signal and adjust C39 (G4) for maximum.

**M.W.**—Switch receiver to M.W., tune to 200 m, feed in a 200 m (1,500 kc/s) signal and adjust C37 (F4) and C32 (F3) for maximum output. Tune receiver to 517 m, feed in a 517 m (580 kc/s) signal and check the calibration. If an error of more than ±1/8 inch is found between the cursor setting and the calibration mark, the fixed tracker C9 may be faulty.

**S.W.**—Switch receiver to S.W., tune to 17.7 m, feed in a 17.7 m (17 Mc/s) signal and adjust C36 (F4) and C31 (F3) for maximum output rocking the gang while adjusting C31 to obtain optimum results. Tune receiver to 50 m, feed in a 50 m (6 Mc/s) signal and check the calibration. Although fixed tracking is employed, some small adjustment can be made at this end of the band by moving the length of wire terminating L6 inside the coil former. Should an error greater than ±1/8 inch still exist between the cursor setting and the calibration mark, the fixed capacitor C8, or the tuning coil L6, may be faulty.

Underside view of the chassis showing all the R.F. and oscillator trimmers. The internal speaker switch S18 is operated by rotating the external speaker plug.

